




11-1 Power Sound Schematic Diagram




4 Signal of HDMI(Data)



7 The Signal are Inputed to IC610




9 Output WaveForm




-This Document can not be used without Samsung's authorization.

12-2 AV Input Tuner Schematic Diagram


SCART1




SCART2




PC ANALOG




HDMI




COM PONENT




VHS_S INPUT




AV_S INPUT




HP_SOUND_OUT




DTV MODULE CONNECTION




ANYNET




MONITOR SOUND OUT




DIGITAL TUNER



SERVICE JACK





ANALOG TUNER



-This Document can not be used without Samsung's authorization.

12-3 MICOM Schematic Diagram









-This Document can not be used without Samsung's authorization.

12-6 DTV Schematic Diagram(1)




-This Document can not be used without Samsung's authorization.

12-7 DTV Schematic Diagram(2)




-This Document can not be used without Samsung's authorization.

12-8 DTV Schematic Diagram(3)



-This Document can not be used without Samsung's authorization.

12-9 DTV Schematic Diagram(4)



11-10

